



CF Moto Horn Kit

Thank you for purchasing XTC Power Products Horn Kit. Our Easy Install kits make us a leader in UTV electrical accessories. This kit is from our Plug & Play product line, with only needing to plug in the power cord.

Please read the instructions fully and familiarize yourself with the components before starting the installation.

1. Mount the Horn, under the right front fender is a ground bolt on the frame, remove the bolt and mount the horn using the factory bolt as shown below. Point the open horn screen down to help keep water and debris from entering the horn.



2. Install Horn Switch – There are several places the Switch can be mounted, so user preference may dictate where it is mounted. Remove one of the dash switch plugs and install the switch.



3. **Hook up the Horn** – Run the Violet and black wires from the switch through the factory grommet to the horn. Attach the Violet and Black wires to the horn terminals, polarity does not matter. Secure the wires from any hot or moving parts with the included cable ties.



4. Hook up Power – Unplug the AUX power connector under the dash, plug our adapter into it and then plug back into the power outlet. It goes inline.



5. Verify Operation.

Secure all installed cables with supplied cable ties making sure they are away from any hot or moving parts.

We can be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
380 E Comstock Dr.
Chandler AZ 85225
480-558-8588
www.xtcpowerproducts.com

*Disclaimer: This kit is intended for off road use only and XTC Motorsports claims no responsibility for its use. It is up to the purchaser to make sure it complies with all Federal, State and Local laws. R1

Copyright © 2025 XTC MOTORSPORTS LLC, all rights reserved.