



## Power Control System PCS-15XP-S+3 Interface Cable

Thank you for purchasing XTC Motorsports Products. This cable allows you to run the PCS-72 STROBE on the 2015 RZR tail lights. This cable is Plug & Play into the OEM rear harness. It also has 3 extra auxiliary wires for Whip, Rear, Rock or any other lights you may have.

Please read the instructions fully and familiarize yourself with the components before starting the install.

1. Unplug the OEM rear light harness near the rear left side.
2. Plug the adapters connectors into the OEM Rear Harness connectors



3. Remove the seats and center plastic tunnel
4. Run the cable through the center of the car up to the dash. **NOTE: Make sure to keep the cable away from any HOT or Moving parts.**
5. Attach the Yellow and Violet wires to the Yellow and Violet PCS-72S terminal.
6. Attach the other wires to any of the other terminals that you want to control.
7. Secure cable with cable ties making sure to keep away from any HOT or MOVING parts.
8. Verify operation
9. Reinstall interior of car.

We can also be reached at [Support@xtcpowerproducts.com](mailto:Support@xtcpowerproducts.com). Please visit our website at

[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

XTC Power Products

A Division of XTC Motorsports LLC

380 E Comstock Dr

Chandler, AZ 85225

480-558-8588

[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

Copyright © 2023 XTC Motorsports LLC, All Rights Reserved