



# Polaris Pulse High Beam Remote Activation Switch

Thank you for purchasing XTC Power Products, Polaris High Beam Activation Relay. No need to add a switch on the dash, this system uses your high beam to turn on and off extra lights.

Please read the instructions fully and familiarize yourself with the components before starting the installation. Quick Install Guide.

1. Locate the Pulse Power Busbar
2. Remove one of the plugs and plug the kit into it.
3. Mount the relay with the supplied screw, Polaris offers spots for this purpose.
4. Un-plug passenger headlight plug and install our adapter then plug our adapter into the headlight.
5. Attach the accessory power wire to the orange and black wire with the supplied heat shrinkable butt connector. Using a heat gun heat the ends of the butt connector to seal.
6. Verify operation, Turn the key on and put headlight switch on high beam and the accessory should turn on.

**Note: The relay comes with a 20 AMP fuse and can be increased to a 30 AMP if needed or reduced. Install the fuse size that the accessory that is being powered calls out for. Always use what the Manufacture recommends.**

For installation help, we can also be reached by email at  
[support@xtcpowerproducts.com](mailto:support@xtcpowerproducts.com)

XTC Power Products  
A Division of XTC Motorsports LLC  
380 E Comstock Dr.  
Chandler AZ 85225  
480-558-8588  
[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

**Copyright © 2024 XTC MOTORSPORTS LLC, all rights reserved.**