




## 2019 RZR Fang Power to Headlight Halo

Thank you for purchasing XTC Power Products Power Harness Light Out. This kit is completely plug and play, no wires to cut, no crimping, just plug it into the OEM harness. Please read the instructions fully and familiarize yourself with the components before starting the install. Quick Install Guide.

1. Remove the Front Grille exposing the rear of the Fang Lights, un-plug either side Fang Light and Plug the new harness in-line. (Drivers side Shown)




2. Run the Harness to the closes Headlight, un-plug the Headlight and remove TPA Lock as shown below




3. Pull the plug out and insert the Terminal into the open cavity and re-install the Lock.



4. Run the end of the Harness to the other Headlight, Keep the Harness away from any Hot or Moving Parts!
5. Insert the Terminal into the Headlight Connector following the same procedure in steps 2 and 3.



Passenger Side Connector



Drivers Side Connector

6. Verify operation, when the Fang Lights are on the Headlight Halo Lights will be on.
7. Secure Harness using the supplied Cable Ties, Keep the Harness away from any Hot or Moving Parts!

We can also be reached at [Support@xtcpowerproducts.com](mailto:Support@xtcpowerproducts.com). Please visit our website at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

XTC Power Products  
A Division of XTC Motorsports LLC  
380 E Comstock Dr  
Chandler, AZ 85225  
480-558-8588  
[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)  
Copyright © 2023 XTC Motorsports LLC, All Rights Reserved